Enabling APD on Landing with Split Screen

Aero App · https://www.aeroapp.info/kb/docs/aeroapp/how-do-i-enable-apd-on-landing-with-split-screen/

Aero App features a split screen that allows users to view charts or user PDF documents simultaneously within the Moving Map, on the same screen.

In order to enable APD on Landing, users must go to Settings > Miscellaneous. Here, users will see the “Switch to APD on Landing” option

Enable the option, and input the speed for when you want the switch to APD to occur.

Now, on the Moving Map, once you cross your threshold speed, the APD on Landing screen will automatically open.